

food **FOOD • 73**
5:00 pm - 6:00pm NEW

Chopped

PG In the series opener, four chefs must use octopus, duck and animal crackers to make an extraordinary three-course meal in three rounds of competition.

rovi



INFO

HGTV • 72

5:29:03

Wed 6/9		5:30 pm	6:00 pm	6:30 pm	7:00 pm	7:30 pm	
ABC.d	07	Eyewitness News		ABC World News	Jeopardy!	Eyewitness Ne...	
E!	09	< 50 Cutest Chi ...	Keeping Up With The Kardashians		Keeping Up Wit ...	Keeping Up Wit ...	
HGTV	10	< Find Your Style	Color Correction	House Hunters	House Hunters	House Hunters	
FOOD	11	Chopped		Chopped	Chopped		
TWC	13	< Weather: PM Edition		Weather Center	The Big Bang Th ...		
SPIKE	16	CSI: Crime Scene Investigation		1,000 Ways To Die		1,000 Ways To Die	
ION	17	Criminal Minds	Criminal Minds		Criminal Minds	Criminal Minds	

DIGITAL
CABLE

GUIDE

Find Shows



List

B

LEARN ABOUT
TV SHOW RATINGS

Passport[®] Guide DVR 7.1 for Cisco Quick Reference Guide

rovi




Digital cable the way it was meant to be

It's time for you to discover digital cable the way it was meant to be—with convenience, variety, and control. Search fast. Save time. Record programs with ease. Find the shows you want to watch when you want to watch them. It's time to engage your television viewing experience and enjoy every minute you spend watching TV.

Time Grid

Passport Guide's easy-to-use Time Grid helps you find shows in seconds. Just press the GUIDE button on your remote to view at least 90 minutes of programming at a glance. Use the arrow buttons to navigate the grid.


Press GUIDE again to find shows by title, keyword, channel, or theme. Press the A button to sort by favorites, only programs in spectacular HD, or from custom-made lists with all the channels *you* like. It's that easy.



Press GUIDE twice to search

Find Shows


Find what you want to watch fast. With just two clicks of your GUIDE button, you can search for shows by title, keyword, channel, or theme to find programs about your favorite actor or topic. You can also find a list of your recorded shows.



Select 'Theme' from Find Shows

Themes

Find shows by themes like Series and Specials, Movies, Sports, Lifestyle, and more. Press SELECT/OK to search sub-themes. Arrow right to navigate the list.



Press INFO from the Time Grid

Program Info

From the Time Grid, press INFO to access the Plot Summary, Cast & Crew, and You Might Like options. From the Cast & Crew list, you can view actors and even schedule DVR recordings.

Info Banner

Press the INFO button once to get information about the program you are currently watching.



Press INFO once

Browse


Press the INFO button twice to get a brief program description. Use the arrow buttons to browse other channels and times without leaving the show you're currently viewing.



Press INFO twice to browse

General Settings


Press MENU twice (Motorola) or SETTINGS and A (Cisco) to personalize your television experience. Adjust My Preferences, Parental Controls, Timers, Remote Access, Purchase Locks and PINS, and more.



Press MENU twice (Motorola) or SETTINGS and A (Cisco) to personalize

DVR



DVR¹ puts you in control. Pause live television. Rewind and replay programs in an instant. With DVR, you can build your own personal library of programs, movies, sports, and more to watch on *your schedule*.




With DVR, you can pause live TV, show an instant replay, and even rewind or fast-forward programming.

- ▶ Play
- ⏸ Pause Live TV
- ↺ Instant Replay
- ⏩ Fast-Forward (3 Speeds)
- ⏮ Rewind (3 Speeds)
- LIVE** Return to Live TV


Set your DVR to record a show or an entire series right from the Time Grid. Press REC on your remote to record.



Press the LIST button to access your recorded shows. Press SELECT/OK to play a program. Press A to group titles and press INFO for group options.



Lost & Found lets you recover² a deleted show from the list. You can also see why a program did not record. Press LIST from Recorded Shows to access Lost & Found.



1—On Demand and DVR not available in all areas. On Demand programs may not be recorded with DVR.

2—Based on available hard drive disc space.

Video on Demand


Enjoy TV shows, movies, and more! On Demand* gives you the convenience to enjoy TV on your schedule without ever having to leave the comfort of your couch.



Press MENU once to access categories such as Movies On Demand from the Quick Menu. Or you can press the On Demand button on your remote or simply tune directly to the On Demand channel.



On Demand movies are grouped by categories. You can order HD movies, new releases and more. Select Rentals to view recently purchased movies and shows.



Find a movie in seconds by navigating with the left and right arrow buttons to choose a subcategory or genre. Then use the up and down arrow buttons to choose a title. Press INFO for more information. Press B to buy. Press PLAY to play a preview.

* On Demand not available in all areas.

Don't just watch TV. Experience it with Passport Guide.