

passport guide quick reference guide





digital cable the way it was meant to be

It's time for you to discover digital cable the way it was meant to be – with convenience, variety and control. Search fast. Save time. Schedule timers with ease. Find the shows you want to watch when you want to watch them. It's time to engage your television viewing experience and enjoy every minute you spend watching TV.

time grid

Passport Guide's easy-to-use **Time Grid** helps you find shows in seconds. Just press the GUIDE button on your remote to view 90 minutes of programming at a glance. Use the arrow buttons to navigate the grid.

Press GUIDE again to find shows by **Title, Channel** or **Theme**. Now you can **Search** smarter and quickly find just what you want to watch.



find shows

Find what you want to watch fast. With just 2 clicks of your GUIDE button, you can search for shows by Title, Channel, or Theme.

Find shows by Themes like Series and

Arrow right to navigate the list.

Specials, Movies, Sports, Lifestyle and





Select 'Theme' from Find Shows

., wallpaper and a baby-size mouse hole. Starring: Genevieve Gorder and Thad

Mills, 30 min, Rated TV-Y, Program Type: Home and Garden/DIY,

11:00 am - 11:30 am

Soon-to-be parents want a play

oom that doubles as an office. The

program info

From the Time Grid press INFO to access More Information Press C to go back.

themes

info banner

Press the INFO button once to get information about the program you are currently watching.



Press INFO once

browse

Press the INFO button twice to get a brief program description. Use the A and • buttons to browse other channels and times without leaving the show you're currently viewing.



Press INFO twice to browse

general settings

Press MENU twice to personalize your television experience. Access Settings to set Favorites, Parental Control, Timers, PINs and more.



Press MENU twice to personalize

Press INFO from the Time Grid

reminder timers


Never miss a program! Use the Guide to set timers to remind you that your favorite program is about to begin.




When in the Guide, highlight a program airing in the future, Press SELECT/OK and choose "**Set Event Timer**" from the options. A reminder timer \bullet will appear next to the title.



The **Channel Banner** displays a reminder message one minute before the program starts. Press SELECT/OK to select the program or simply wait for the set-top box to tune to the program automatically.



To review, modify or clear timers, press Menu twice to access **General Settings**. Press ▲ ▼ buttons to highlight Alert Summary and press SELECT/OK.



Alert Summary will list each timer scheduled. To change the status of a timer, press the ▲ ▼ buttons to highlight a timer then press the SELECT/OK buttons to Cancel option.

video on demand


Enjoy TV shows, movies and more! On Demand* gives you the convenience to enjoy TV on your schedule without ever having to leave the comfort of your couch.



Press MENU once to access categories such as **Movies On Demand** from the Quick Menu'. Or you can press the On Demand button on your remote or simply tune directly to the On Demand channel.



On Demand movies are grouped by **categories**. You can order HD Movies, New releases and more. Select "My Rentals" to view recently purchased movies and shows.



Find a movie in seconds by navigating with

↑ to choose a subcategory or genre, and

↑ to choose a title. Press INFO for more information. Press B to buy. Press

to play a preview.

^{*} On Demand not available in all areas.

Don't just watch TV. Experience it with Passport Guide.